





















2022-0038  
05/2023

## PRZEGLĄD LAMP UV

<b>Produkt</b>	<b>Szpachla UV</b>	<b>Podkład gruntujący UV</b>	<b>Lakier bezbarwny UV</b>
<b>Lampa UV</b>			
<b>IRT UVA 1 PREPCURE 3 (395 nm)</b>	 100 x 100 cm  55 cm  5 min	 100 x 100 cm  55 cm  5 min	 20 x 30 cm  20-30 cm  5 min
<b>IRT UVA 1 PREPCURE 4 (395 nm)</b>	 100 x 100 cm  55 cm  5 min	 100 x 100 cm  55 cm  5 min	 20 x 30 cm  20-30 cm  5 min
<b>IRT UVA 2 PREPCURE 4 (395 nm)</b>	 100 x 100 cm  55 cm  5 min	 100 x 100 cm  55 cm  5 min	 20 x 30 cm  20-30 cm  5 min
<b>IRT COMBI 4-1 IR-UVA (395 nm)</b>	 100 x 100 cm  55 cm  5 min	 100 x 100 cm  55 cm  5 min	 20 x 30 cm  20-30 cm  5 min
<b>IRT COMBI 4-2 IR-UVA (395 nm)</b>	 100 x 100 cm  55 cm  5 min	 100 x 100 cm  55 cm  5 min	 20 x 30 cm  20-30 cm  5 min
<b>IRT COMBI 4-10 IR-UVA (395 nm)</b>	 100 x 100 cm  55 cm  5 min	 100 x 100 cm  55 cm  5 min	 20 x 30 cm  20-30 cm  5 min









2022-0038  
05/2023

<p><b>IRT COMBI 4-20 IR-UVA (395 nm)</b></p>	 100 x 100 cm  55 cm  5 min	 100 x 100 cm  55 cm  5 min	 20 x 30 cm  20-30 cm  5 min
<p><b>IRT SpotCure (LED – 395 nm)</b></p>	 10 cm  10 cm  2 min	 10 cm  10 cm  2 min	
<p><b>IRT SpotCure2 (LED – 395 nm)</b></p>	 15 x 30 cm  10 cm  1 min 30 s	 15 x 30 cm  10 cm  1 min	
<p><b>IRT Smart Cure (LED – 395 nm)</b></p>	 10 cm  10 cm  2 min 30 s	 10 cm  10 cm  2 min	
<p><b>SpectrateK Instacure UVLED (LED – 395 nm)</b></p>	 10 cm  10 cm  3 min	 10 cm  10 cm  3 min	
<p><b>TESLA Cure R100 (LED – 395 nm)</b></p>	 10 cm  10 cm  3 min	 10 cm  10 cm  2 min	
<p><b>Scangrip UV gun (LED – 395 nm)</b></p>	 10 cm  10 cm  3 min	 10 cm  10 cm  2 min	



2022-0038  
05/2023

<b>Scangrip NOVA-UV S</b> (LED – 390 nm)	 10 cm	 10 cm	
	 10 cm	 10 cm	
	 3 min	 2 min	